



EAR IMPRESSIONS

ALL OF OUR HANDCRAFTED CUSTOM IN-EAR MONITORS REQUIRE A FULL SHELL IMPRESSION. THIS REQUIRES THE ASSISTANCE OF A PROFESSIONAL AUDIOLOGIST

REQUIREMENTS

The impressions should display the full contour of both the outer ear and the ear canal, to a sufficient depth. The photos on the left are a perfect example of an excellent ear impression as provided by TheHeadphoneList.com.

Each ear impression must include the full helix, crus of the helix, tragus and antitragus.

IMPORTANT: The impression must be taken just past the second bend of the ear canal.

The material utilized to shoot the impression must be made of high-viscosity silicone.

The impression must be taken with the client's mouth open. We recommend that a 1-2" bite block is used. Utilizing this method

will reduce movement and will result in a more secure fitment as well as an optimum seal for maximum performance from your Empire custom in-ear monitors.

If you have any questions at all or are unsure if your impressions meet the requirements please send detailed photos to our support team at Support@EmpireEars.com

Once you receive your impressions, please ship them to the following address:

Empire Ears
5600 Oakbrook Pkwy.
Suite 100
Norcross, GA 30093

