

# Chord Poly Wireless Streamer

## Set-Up Tips



1. Read the manual carefully.
2. Fully charge your Poly before use.
3. For the best charge, use a charger with a 2-amp output. Most phone chargers and USB ports only output 1 amp, but some tablet chargers are 2-amp. While Poly will charge with a 1-amp device, it will take twice as long to charge. When charging Poly for the first time on a 1-amp device, allow it to charge for 10 hours.
4. Poly is only compatible with 2.4 GHz networks. Mesh networks should automatically detect this.
5. Before setting up the device, make sure you have the name (SSID) and password for your WiFi network.
6. Fill in all three fields in the setup menu. If *Name*, *SSID*, or *Password* is not completed you will not connect to the network. (It may look like *Name* is auto-populated, but it is not.)
7. Bluetooth is inaccessible while Poly is in Access Point Mode. To configure Bluetooth, first connect Poly to a WiFi network.
8. Micro SD cards should be in ExFAT format. FAT32 may work but is not recommended.
9. Recommended apps for playback and control:

iOS UPnP/DLNA	8Player (paid version)
Android UPnP/DLNA	BubbleUPnP (paid version)
Computer	Roon <i>*Poly is not a Roon Core device</i>
MPD for iOS/Android	Soundirok
MPD for Android	M.A.L.P

10. Use of the Micro SD card requires 8Player or BubbleUPnP.
11. The Mobile Hotspot feature is not available yet. Future use of this feature may require activation from your wireless provider.
12. Poly is not a plug-and-play device. Proper use requires some networking experience and a solid network infrastructure.



# Chord Poly Wireless Streamer

## Charging Tips



Chord Electronics Ltd.

1. Poly does not come with its own charger, but you probably already have what you need.
2. Like Mojo, Poly uses a Micro USB port for charging. That means any modern smart phone USB charger will work as long as it is 5v 1 amp rated. Check the small print on any charger before you use it.
3. When connected to Mojo, Poly can charge both units simultaneously with a 2-amp charger. Each device can be charged separately with 1-amp chargers.
4. Computer USB ports are only rated at 0.5 amps and will not properly charge Poly.
5. The P.status LED light will be a solid white while Poly is charging. It will change to solid blue when Poly reaches a full charge.
6. If your Poly and Mojo will remain connected to a power supply, turn the devices off when they are not in use. This will allow the battery to stop receiving power once it is fully charged and prevent its lifespan from decreasing.

## Charging Times

2-Amp Charger	Poly	Mojo	Playback
Charging Only	4 hours	4 hours	9 hours
Charging with Playback	4 hours	8 hours	9 hours

## Status Indicators

P.status  
M.status

Poly battery status  
Mojo battery status

○ White	Charging
● Blue	75-100%
● Green	50-75%
● Yellow	25-50%
● Red (solid)	5-25%
● Red (blinking)	less than 5%

